


Software DokuStar



- System requirements:
- Software: Windows XP, Windows Vista, Windows 7 (requires administrator rights)
- Hardware: Pentium-PC (1000 MHz or more), 256 MB RAM (512 MB recommended), 150 MB free hard drive space, Super VGA monitor (with 1024x768 resolution), small letter adjustment), 24 Bit Tru Color, free COM or USB port, mouse
- Visualization and data storage

Technical data	Software DokuStar	Software DokuStar Plus
For	DPS 101, DPS 109 and DPG 202	DPG / DPS 109 and direct connection
Measuring channel	up to 2	up to 16
PC min.	Pentium 160 MHz	Pentium 160 MHz
RAM	64 MB	64 MB
Interface	RS-232 or USB	RS-232 or USB
Interfaces	RS-232 or USB	RS-232 or USB
Memory	15 MB free HD memory	15 MB free HD memory

Order number		
Software DokuStar	PT 882 500	PT 882 501

Further accessories

Power cords	Order number
Mains cable, US plug, 2.5 m	P4 564 309 YX
Mains cable, U.K. plug, 2.5 m	P4 564 309 Y1
Mains cable, Swiss plug, 2.5 m	P4 564 309 YR
Mains cable, Euro-style safety plug, 2.5 m	P4 564 309 YU

Interface cable	Order number
Interface cable, M12 m/M12 m, 0,7 m	PM 061 281 -T
Interface cable, M12 m/M12 m, 1.0 m	PM 061 282 -T
Interface cable, M12 m straight / M12 m straight, 3.0 m	PM 061 283 -T
Interface cable, M12 m/M12 m, 5.0 m	PM 061 284 -T
Interface cable, M12 m/M12 m, 10 m	PM 061 285 -T
Interface cable, M12 m/M12 m, 15 m	PM 061 286 -T
Interface cable, M12 m/M12 m, 20 m	PM 061 287 -T
Interface cable, M12 m/M12 m, 50 m	PM 061 289 -T

Further accessories	Order number
Connector M12 to RS-485	PM 061 270 -X
Plug-in bus termination for RS-485, M12 5-pole	PT 348 105-T
Y-Connector M12 to RS-485	P 4723 010
USB converter to RS-485 interface	PM 061 207 -T
Adapter M12/M12 (only RS-485, no power)	PM 348 132 -T
Gauge adapting cable RS-485, D-Sub 9-pole/M12 5-pole	PT 348 131 -T
Connection cable, RS-485, M12/D-sub 9-pole, 3.0 m	PT 348 223 -T